

Instruction Manual for Bimetal Thermometer for Oven

Thank you for purchasing Bimetal Thermometer for oven.

- This product is designed to measure inside temperature of oven. Do not use it for other purposes.
- Read this manual thoroughly before using the bimetal thermometer. Keep the manual in a safe place for future references whenever necessary.

Specifications

Product	: No. 1726-20 Bimetal thermometer for oven
Measuring range	: 0 to 300°C
Min. graduation	: 10°C
Accuracy	: ±10°C
Materials	: Case : stainless steel Window : glass
Outer dimensions	: 62mm dia. x 67mm
Weight	: 40g

How to use

1. Place (put or hang it) the thermometer in an oven.
2. Read the temperature through the oven window.

Cautions

For your safety and proper use of the thermometer, be sure to observe the following:

- Never use the thermometer in 300°C or higher temperature.
- Do not drop or apply shock to the thermometer. Otherwise, malfunctions may occur.
- Do not wash the thermometer with water.
- Clean the thermometer with a kitchen paper or like if the unit becomes dirty.
- After taking the measurement, the unit becomes very hot. Never directly touch the thermometer avoiding to get burned you.
- This thermometer cannot be used for approval purpose.

Maintenance

For accurate measurements, it is desirable to confirm the accuracy of the bimetal thermometer in comparison with the standard or reliable thermometer once a year.

SATO KEIRYOKI MFG. CO., LTD.

3-4, Kanda-kajicho, Chiyoda-ku, Tokyo 101-0045 Japan
URL: <http://www.sksato.co.jp/english/>