

- * To initialize, tap HOUR key while tapping SEC key.
- * If TIME key is tapped before counting, the target time area on the screen will navigate the time when the alarm activates for 5 seconds.
- 4. Tap START/STOP key to begin a countdown. The target time area displays the scheduled alarm time then.
 - * To pause counting, tap START/STOP key. Tapping the same key resumes counting and updates the scheduled alarm time.
 - * If counting is longer than 30 minutes, an advance alarm activates for 5 sec. when it leaves 30 min. to zero.
- 5. The alarm activates for 30 seconds when the counting finishes. Tapping any key can stop it.

TARGET TIME Mode—to set the time when the alarm activates—

1. Tap TARGET TIME key. The target time area on the screen blinks then.
2. Tap HOUR, MIN, and SEC keys to set the alarm time. Tap and hold the key to increment the value rapidly.
3. Stay idle for 10 seconds or tap TARGET TIME key again to confirm the value.
 - * To initialize, tap HOUR key while tapping SEC key.
 - * If TIME key is tapped before counting, the timer area on the screen will navigate the countdown length for 5 seconds.
4. Tap START/STOP key to begin a count-up. The timer area displays the remaining time length then.
 - * To pause counting, tap START/STOP key. Tapping the same key resumes counting and updates the remaining time without changing the alarm time.
 - * If counting is longer than 30 minutes, an advance alarm activates for 5 sec., 30 min. before the alarm time.
5. The alarm activates for 30 seconds when the counting finishes. Tapping any key can stop it.

Battery Replacement

1. Flip up the frame stand and slide down the battery lid.
2. Exchange batteries in a correct polarity and put the battery lid back.

Specifications

Product name	Target Timer
Model no.	TM-33T
Catalog no.	1802-00 (Pink), 1802-02 (Green)
Power	AAA battery x 2
Battery life	6 months if alarm beeps once a day without vibration Attached batteries are for test purpose and may last shorter.
Material	ABS resin
Dimensions	95 (W) x 85 (H) x 20 (D) mm
Weight	133 g including batteries
Accessories	AAA alkaline battery x 2

Specifications and appearance are subject to change for improvement.
For details, contact us or a retailer from which you have purchased.

Warranty Policy

Our products are warranted to be free from defects in materials and workmanship for a period of one year from date of delivery. If repair is necessary and has not been the result of misuse, force majeure, or transportation arranged by yourself within the one-year period, please return the products on freight prepaid basis. Correction of the defect will be made without charges. We alone will determine if the product problem is due to deviations or customer misuse. Out-of-warranty products will be repaired for a fee. Before returning, request for our acknowledgement first.

SATO KEIRYOKI MFG. CO., LTD.

3-4, Kanda-kajicho, Chiyoda-ku, Tokyo 101-0045, Japan
<https://www.sksato.co.jp/en/>