

Instruction Manual for Sandglasses

Thank you for purchasing the sandglass.

The sandglass is designed to have elapse time by a given amount of falling iron sand. Do not use it for other purposes. Read this manual thoroughly before using and keep it in a safe place for your future references.

Specifications

Cat. Number	Elapse time	Accuracy	Materials		
			Frame	Container	Sand
1734-01	One minute	±5 sec.	Wood	Hard glass	Iron sand
1734-20	Two minutes	±5 sec.	Wood	Hard glass	Iron sand
1734-30	Three minutes	±5 sec.	Wood	Hard glass	Iron sand
1734-50	Five minutes	±5 sec.	Wood	Hard glass	Iron sand
1734-10	Ten minutes	±10 sec.	Wood	Hard glass	Iron sand

How to use

- . Use the sandglass placing horizontally on a steady position.
- . Use the sandglass after confirming that the sand completely runs into the lower half.

Warnings

- Never get the magnet close to the sandglass since the magnetite sand is used.
- Do not strongly shake the sandglass or drop it down. If so the glass may be broken.
- Operation ambient is -10 to 110°C. Never use the sandglass in the high temperature state (more than 110°C) or the place condensation occurs. If used, you may get burned or it may cause the malfunction.
- Be careful not to put the sandglass closer to fire or oven when you do the cooking or so.
- If the glass was broken and the iron sand or broken pieces of glass get into someone's eye, immediately consult with doctors.
- Keep the sandglass out of the reach of children.

SATO KEIRYOKI MFG. CO., LTD.

No. 3 Nishi-Fukudacho, Kanda, Chiyodaku, Tokyo 101-0037 Japan

URL: <http://www.sksato.co.jp/english/>